



Original	Replacement	Original	Replacement
 Power	 Power	 Hold/EPG	 Guide
 Mute	 Mute	 Red	 Red
 1	 1	 Green	 Green
 2	 2	 Yellow	 Yellow
 3	 3	 Blue	 Blue
 4	 4	 Vol+	 Vol +
 5	 5	 Vol-	 Vol -
 6	 6	 I-II	 Dual
 7	 7	 Source	 AV
 8	 8	 Freeze	 Options
 9	 9	 CH+	 Ch +
 0	 0	 CH-	 Ch -
 Back/S.Page	 Back	 Sleep	 Sleep
 Text	 Text	 Menu	 Menu
 Index/PVR List	 Smart	 DTV/Radio	 TV/R
 Rec/Reveal	 Rec	 Exit	 Exit
 Zoom/T.Shift	 Eject	 Aspect	 3D





Original	Replacement	Original	Replacement
P.MODE	Format	FAV	Pre Ch
S.Mode	+ Shift + Dual	FAV+/Repeat	+ Shift + Ch +
Up	Up	FAV-/A-B	+ Shift + Ch -
Down	Down		
Right	Right		
Left	Left		
OK	Ok		
Media	Media		
Info/Slow	Info		
Step/Subtitle	Subt		
Play	Play		
Pause	Pause		
I<<	I<<		
>>I	>>I		
Stop	Stop		
<<	<<		
>>	>>		

