































































Original	Replacement	Original	Replacement
 Power	 Power	 i	 DISPLAY INFO Info
 Mute	 MUTE Mute	 Up	 Up
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 Left	 Left
 4	 4	 OK	 OK Ok
 5	 5	 V +	 + VOL Vol +
 6	 6	 V -	 - VOL Vol -
 7	 7	 TV / Radio	 SEARCH TVR TV/R
 8	 8	 List	 DISC NAV LIST List
 9	 9	 P +	 + CH Ch +
 0	 0	 P -	 - CH Ch -
 Back	 RETURN BACK Back	 Red	 A Red
 APP	 APP MEDIA Media	 Green	 B Green
 Menu	 TOP MENU MENU Menu	 Yellow	 C Yellow
 Exit	 CLEAR EXIT Exit	 Blue	 D Blue
 EPG	 -/-- GUIDE Guide	 Audio	 SOUND DUAL Dual



