










































































Original	Replacement	Original	Replacement
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TTX/MIX		Text
	PRE-CH		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	CH List		List
	CH+		Ch +
	CH-		Ch -
	Settings		Options
	Home		Smart
	Guide		Guide
	E-Manual		D. Menu
	Info		Info
	Return		Back
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Red		Red
	Green		Green





Original		Replacement		Original		Replacement	
	Yellow		Yellow				
	Blue		Blue				
	Pic Size		3D				
	AD/Subt.		Subt				
	Picture		Format				
	<</ <<		<<				
	Stop		Stop				
	Play		Play				
	Pause		Pause				
	>>/>>		>>				

