



Original	Replacement	Original	Replacement
Power	Power	FAV	Pre Ch
Mute	Mute	Page+	Ch +
1	1	Page-	Ch -
2	2	Up/CH+	Up
3	3	Down/CH-	Down
4	4	Right	Right
5	5	Left	Left
6	6	OK	Ok
7	7	Vol+	Vol +
8	8	Vol-	Vol -
9	9	Red	Red
0	0	Green	Green
Info	Info	Yellow	Yellow
Recall	Back	Blue	Blue
Menu	Menu	Audio	Dual
EPG	Guide	Pause	Pause
Exit	Exit	TTX	Text





Original	Replacement	Original	Replacement
 Subtitle	 Subt		
 Tv/Radio	 TV/R		

