



Original	Replacement	Original	Replacement
 Power	 Power	 Rec	 Rec
 D/A Input	 Shift + AV	 I<<	 I<<
 Tv/Radio	 TV/R	 <<	 <<
 Input	 AV	 >>	 >>
 Bright -	 Shift + Left	 >>I	 >>I
 Bright +	 Shift + Right	 Back	 Back
 Simplink	 Media	 DVR	 Smart
 Text	 Text	 Menu	 Menu
 Info	 Info	 Exit	 Exit
 Live TV	 Shift + Smart	 Guide	 Guide
 Red	 Red	 Up	 Up
 Green	 Green	 Right	 Right
 Yellow	 Yellow	 Down	 Down
 Blue	 Blue	 Left	 Left
 Stop	 Stop	 OK	 Ok
 Play	 Play	 Vol+	 Vol +
 Pause	 Pause	 Vol-	 Vol -





















































Original	Replacement
FAV	Pre Ch
Mute	Mute
PR+	Ch +
PR-	Ch -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
List	List
Q.View	D. Menu
[≡x]/Update	Eject

Original	Replacement
[≡i]/Index	Shift + Info
[≡o]/Time	Shift + Exit
Sleep	Sleep
[≡+]/Hold	3D
[≡?]/Reveal	Options
Subtitle	Subt
Ratio	Format
I/II	Dual













































Original		Replacement		Original		Replacement	
	Power		Power		4		4
	Stop		Stop		5		5
	Play		Play		6		6
	Pause		Pause		7		7
	I<<		I<<		8		8
	<<		<<		9		9
	>>		>>		0		0
	>>I		>>I				
	Menu		Menu				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	OK		Ok				
	1		1				
	2		2				
	3		3				





Original		Replacement		Original		Replacement	
	Power		Power		8		8
	Input		AV		9		9
	Stop		Stop		0		0
	Play		Play				
	Pause		Pause				
	Rec		Rec				
	<<		<<				
	>>		>>				
	PR+		Ch +				
	PR-		Ch -				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				

