











































































Original	Replacement	Original	Replacement
 Power	 Power	 V -	 Vol -
 Mute	 Mute	 Red / Status	 Red
 1	 1	 Green / Sleep	 Green
 2	 2	 Green / Sleep	 Shift + Power
 3	 3	 Blue / Review	 Blue
 4	 4	 Yellow / V-PP	 Yellow
 5	 5	 Yellow / V-PP	 Format
 6	 6	 Size	 3D
 7	 7	 Zoom	 Eject
 8	 8	 TV / TXT	 Text
 9	 9	 Cancel	 Back
 0	 0	 Index	 Info
 -/--	 Guide	 Stop	 Stop
 TV / AV	 AV	 Up / P +	 Up
 P +	 Ch +	 Down / P -	 Down
 P -	 Ch -	 Right / V +	 Right
 V +	 Vol +	 Left / V -	 Left





Original	Replacement	Original	Replacement
	Menu		Menu
	Menu		Ok

