



































































Original		Replacement		Original		Replacement	
	Power		Power		7		7
	Mute		Mute / Dimmer		8		8
	Audio		Audio / Lang I/II		9		9
	TV / STB		AV / Input / RDS		0		0
	TV / R		TV/Radio /		SAT		Shift + 0
	Sleep		Sleep / Timer		EPG		Guide / EPG / -/-
	SUB		Subtitle / EQ		Fav		Fav / Marker / PC
	TXT		Text / Goto		PGUP		CH+ / Page+
	Multi		Display / Media		PGDN		CH- / Page-
	P / N		Picture / Format		Up		Up
	Recall		Back / Return		Right		Right
	1		1		FAV +		Vol+
	2		2		FAV -		Vol-
	3		3		Down		Down
	4		4		Left		Left
	5		5		OK		OK
	6		6		Menu		Menu / Home





Original	Replacement
	 Exit / Cancel / Clear
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Pause / Step / Freeze
	 Zoom / Size
	 D.Menu / Top
	 Info / Angle
	 Shift + 8
	 Shift + Yellow / YouTube /
	 Shift + Text /
	 Shift + 1
	 Shift + 2
	 Eject / Surround
	 Stop / Hold
	 Rec / Rec Mode

Original	Replacement
	 Sound / Title
	 << / Tune-
	 >> / Tune+
	 Smart / List
	 Play / Slow
	 I<< / Preset-
	 Setup / OPT /
	 >>I / Preset+

