


















Original	Replacement
 Power	 Power
 Source	 AV
 Display	 Info
 Freeze	 Pause
 Sleep	 Sleep
 On / Off	 Text
 Mix	 Shift + Text
 Index	 List
 Size	 Eject
 Reveal	 Media
 Update	 Smart
 Subpage	 Subt
 Hold	 Stop
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue

Original	Replacement
 Vol +	 Vol +
 Vol -	 Vol -
 Mute	 Mute
 CH +	 Ch +
 CH -	 Ch -
 Pic Mode	 Format
 I/II	 Dual
 Sound Sys	 Shift + Dual
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 Menu	 Menu
 1	 1
 Menu	 Ok
 2	 2
 3	 3



