



Original	Replacement
Power	Power
Direct Tv Rec	Shift + Rec / Rec Mode
Tv Aspect/AV Link	Picture / Format
Tv/Text	Text / Goto
1	1
2	2
3	3
Tracking/V-Lock+	CH+ / Page+
4	4
5	5
6	6
Tracking/V-Lock-	CH- / Page-
7	7
8	8
9	9
Vol+	Vol+
AV/Input Select	AV / Input / RDS

Original	Replacement
0	0
-/--	Guide / EPG / -/--
Vol-	Vol-
Library/Search	Red / Netflix / Search
I<< Index	I<< / Preset-
Index >>I	>>I / Preset+
ShowView	Info / Angle
Still Album	Smart / List
Replay	Back / Return
Pause/Step	Pause / Step / Freeze
Rec	Rec / Rec Mode
Menu	Menu / Home
Up	Up
Play	Play / Slow
Exit	Exit / Cancel / Clear
Left	Left
<< / Tune-	<< / Tune-

































Original	Replacement
	OK
	Right
	>> / Tune+
	Down
	Stop / Hold
	Shift + Up
	Shift + Right
	Shift + Vol+
	Shift + CH+ /
	Shift + Down
	Shift + Left
	Shift + Vol-
	Shift + CH- /
	TV/Radio /
	Shift + Exit / Cancel / Clear
	Setup / OPT /
	Sleep / Timer

Original	Replacement
	Shift + Sleep / Timer
	Audio / Lang I/II
	Display / Media
	Green / APP / Repeat





Original	Replacement
 Power	 Power
 Tv Aspect/AV Link	 Picture / Format
 Tv/Text	 Text / Goto
 1	 1
 2	 2
 3	 3
 Tracking/V.Lock+	 CH+ / Page+
 4	 4
 5	 5
 6	 6
 Tracking/V.Lock-	 CH- / Page-
 7	 7
 8	 8
 9	 9
 Vol+	 Vol+
 AV/Input Select	 AV / Input / RDS
 0	 0

Original	Replacement
 -/--	 Guide / EPG / -/--
 Vol-	 Vol-
 Prog./Check Up	 Up
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Date+	 Right
 Yellow	 Yellow / YouTube / Repeat
 On+	 Shift + Vol+
 Blue	 Blue / Prime Video / Random
 Off+	 Shift + CH+ /
 Prog./Check Down	 Down
 Date-	 Left
 On-	 Shift + Vol-
 Off-	 Shift + CH- /

