







































































Original	Replacement	Original	Replacement
	Power		Power
	Input		AV
	Home		Shift + Smart
	YouTube		Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	FAV		Pre Ch
	Mute		Mute
	Info		Info
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	Q.View		Options
	Guide		Guide
	Menu		Menu
	Return		Back
	Exit		Exit
	3D		3D
	CH.List		List
	MTS/SAP		Dual
	CC		Subt
	Q.Menu		D. Menu
	OK		Ok
	Up		Up
	Down		Down





Original	Replacement	Original	Replacement
 Right	 Right		
 Left	 Left		
 Sleep	 Sleep		
 S.Mode	 Shift + Dual		
 USB	 Media		
 P.Mode	 Shift + Format		
 H.Lock	 Shift + Stop		
 P.Size	 Format		
 Red	 Red		
 Play	 Play		
 Pause	 Pause		
 Green	 Green		
 <<	 <<		
 Yellow	 Yellow		
 >>	 >>		
 Blue	 Blue		
 Stop	 Stop		

