



Original	Replacement
 Power	 Power
 Mute	 Mute
 TV / AV	 AV
 ?	 Smart
 Lock	 List
 Text	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide

Original	Replacement
 QV	 Pre Ch
 Aspect	 Format
 Subcode	 Subt
 Mix	 Shift + Text
 Cancel	 Exit
 Red / Picture	 Red
 Red / Picture	 Shift + Format
 Green / Sleep	 Green
 Green / Sleep	 Sleep
 Yellow / Timer	 Yellow
 Yellow / Timer	 TV/R
 Blue / Sound	 Blue
 Blue / Sound	 Shift + Dual
 Reveal	 Info
 Hold	 Stop
 - S ←	 Dual
 - P ←	 Options





Original	Replacement	Original	Replacement
Up / P +	Ch +		
Up / P +	Up		
Down / P -	Ch -		
Down / P -	Down		
Right / V +	Right		
Right / V +	Vol +		
Left / V -	Left		
Left / V -	Vol -		
Menu	Menu		
Menu	Ok		

