











































































































































Original	Replacement	Original	Replacement
	On		Power
	Standby		Shift + Power
	V1		1
	V2		4
	V3		7
	Multi CH		8
	DVD		2
	Tape		5
	Tuner		6
	CD		3
	Tuner/Dimmer		0
	Tuner/Dimmer		Shift + Mute / Dimmer
	Sleep		Sleep / Timer
	CH/Disc+		CH+ / Page+
	Vol+		Vol+
	CH/Disc-		CH- / Page-
	Vol-		Vol-
	SP A/B		Sound / Title
	Up		Up
	Muting		Mute / Dimmer
	Left		Left
	Enter		OK
	Right		Right
	Return		Back / Return
	Down		Down
	Setup		Setup / OPT /
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	Stop		Stop / Hold
	<<		<< / Tune-
	>>		>> / Tune+
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	Stereo		Red / Netflix / Search





Original	Replacement	Original	Replacement
	On		Power
	Standby		Shift + Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	+10		Guide / EPG / -/--
	0		0
	CLR		Exit / Cancel / Clear
	CH/Disc+		CH+ / Page+
	CH/Disc-		CH- / Page-
	Top Menu		D.Menu / Top
	Up		Up
	Muting/Previous Menu		Menu / Home
	Muting/Previous Menu		Mute / Dimmer
	Left		Left
	Enter		OK
	Right		Right
	Return		Back / Return
	Down		Down
	Setup		Setup / OPT /
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	Stop		Stop / Hold
	<<		<< / Tune-
	>>		>> / Tune+
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	Audio		Audio / Lang I/II





Original	Replacement	Original	Replacement
	On		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	CH/Disc+		CH+ / Page+
	CH/Disc-		CH- / Page-
	Guide		Guide / EPG / -/--
	Up		Up
	Muting/Previous Menu		Menu / Home
	Muting/Previous Menu		Mute / Dimmer

Original	Replacement	Original	Replacement
	Left		Left
	Enter		OK
	Right		Right
	Down		Down
	Setup		Setup / OPT /
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	Stop		Stop / Hold
	<<		<< / Tune-
	>>		>> / Tune+
	On CD		Shift + Power
	Standby CD		Shift + Mute / Dimmer
	1 CD		Shift + 1
	2 CD		Shift + 2
	3 CD		Shift + 3
	4 CD		Shift + 4
	5 CD		Shift + 5























































Original	Replacement
6 CD	+ Shift + 6
7 CD	+ Shift + 7
8 CD	+ Shift + 8
9 CD	+ Shift + 9
+10 CD	+ Shift + Guide / EPG / -/-
0 CD	+ Shift + 0
CLR CD	+ Shift + Exit / Cancel / Clear
CH/Disc + CD	+ Shift + CH+ /
CH/Disc- CD	+ Shift + CH- /
Pause CD	+ Shift + Pause / Step /
Play CD	+ Shift + Play /
Stop CD	+ Shift + Stop /
<< CD	+ Shift + << /
>> CD	+ Shift + >> /
I<< CD	+ Shift + I<< / Preset-
>>I CD	+ Shift + >>I / Preset+
Random CD	+ Shift + Blue / Prime Video / Random

Original	Replacement
Repeat CD	+ Shift + Green / APP /
Display CD	+ Shift + Display / Media





Original	Replacement	Original	Replacement
	On		Power
	Standby		Shift + Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	CH+		CH+ / Page+
	CH-		CH- / Page-
	Up		Up
	Left		Left
	Enter		OK
	Right		Right
	Down		Down
	Setup		Setup / OPT /
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	Stop		Stop / Hold
	<<		<< / Tune-
	>>		>> / Tune+

