































































Original	Replacement
 Power	 Power
 Eject	 Eject
 I<<	 I<<
 >>I	 >>I
 <<	 <<
 >>	 >>
 Play / Pause	 Play
 Play / Pause	 Pause
 Stop	 Stop
 TV/TXT /	 Shift + Text
 TV/TXT /	 List
 Cancel / Zoom	 Shift + Exit
 Reveal / Subtitle	 Shift + Subt
 Hold / Menu	 Shift + Stop
 Hold / Menu	 D. Menu
 Size / Angle	 3D
 Subpage / Title	 Shift + List

Original	Replacement
 Index / Goto	 Info
 Red / Program	 Red
 Green / Slow	 Green
 Yellow / Repeat	 Yellow
 Blue / A-B	 Blue
 CH +	 Ch +
 CH -	 Ch -
 Sys-Menu	 Menu
 Input	 AV
 Vol +	 Vol +
 Vol -	 Vol -
 DVD	 Media
 DVD-Setup	 Options
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right





Original	Replacement	Original	Replacement
 Down	 Down	 Nicam / A2	 Shift + Mute
 DVB	 Smart	 Mute	 Mute
 Sys-Exit	 Exit	 Sleep	 Sleep
 1	 1	 TV / Radio	 TV/R
 2	 2	 FAV	 Pre Ch
 3	 3	 Fav +	 Shift + Right
 4	 4	 Fav -	 Shift + Left
 5	 5	 Pic. Format	 Format
 6	 6	 Subtitle	 Subt
 7	 7	 Text	 Text
 8	 8	 Display	 Shift + Info
 9	 9	 Language	 Dual
 0	 0	 EPG	 Guide
 -/--	 Shift + Guide		
 Recall	 Back		
 Picture	 Shift + Format		
 Sound	 Shift + Dual		

Original	Replacement	Original	Replacement
 Nicam / A2	 Shift + Mute	 Mute	 Mute
 Mute	 Mute	 Sleep	 Sleep
 Sleep	 Sleep	 TV / Radio	 TV/R
 TV / Radio	 TV/R	 FAV	 Pre Ch
 FAV	 Pre Ch	 Fav +	 Shift + Right
 Fav +	 Shift + Right	 Fav -	 Shift + Left
 Fav -	 Shift + Left	 Pic. Format	 Format
 Pic. Format	 Format	 Subtitle	 Subt
 Subtitle	 Subt	 Text	 Text
 Text	 Text	 Display	 Shift + Info
 Display	 Shift + Info	 Language	 Dual
 Language	 Dual	 EPG	 Guide
 EPG	 Guide		

