







































































Original		Replacement		Original		Replacement	
	Power		Power		1		1
	Mute		Mute		2		2
	Play		Play		3		3
	Pause / Mix		Pause		4		4
	Pause / Mix		Shift + Text		5		5
	Stop / Hold		Stop		6		6
	Size		Format		7		7
	<< / Timer		<<		8		8
	<< / Timer		Shift + Power		9		9
	I<< / Index		I<<		0		0
	>>I / Reveal		>>I		Settings		Options
	>> / Cancel		>>		Exit		Exit
	>> / Cancel		Shift + Exit		Up		Up
	Info		Info		Left		Left
	Audio / I/II		Dual		OK		Ok
	Text		Text		Right		Right
	Back / Del		Back		Down		Down









































































Original	Replacement
Netflix	Media
Vol +	Vol +
Vol -	Vol -
YouTube	Shift + Media
Home / Source	AV
Home / Source	Smart
P +	Ch +
P -	Ch -
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
EPG	Guide
List	List
Q.Menu	Menu

Original	Replacement





























Original	Replacement	Original	Replacement
 Power	 Power	 Blue	 Blue
 Mute	 Mute	 Q.Menu	 D. Menu
 1	 1	 Back	 Back
 2	 2	 Up	 Up
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 Left	 Left
 6	 6	 OK	 Ok
 7	 7	 Menu	 Menu
 8	 8	 EPG	 Guide
 9	 9	 YouTube	 Shift + Media
 0	 0	 Vol +	 Vol +
 Info	 Info	 Vol -	 Vol -
 Audio / I/II	 Dual	 Home / Source	 AV
 Red	 Red	 Home / Source	 Smart
 Green	 Green	 Text	 Text
 Yellow	 Yellow	 P +	 Ch +





Original	Replacement	Original	Replacement
	P -		Ch -
	List		List
	Netflix		Media
	Play		Play
	Pause		Pause
	Stop		Stop
	Rec		Rec
	<<		<<
	<<		<<
	>>		>>
	>>		>>
	Exit		Exit

