



Original	Replacement	Original	Replacement
 Power	 Power	 Right	 Right
 Mute	 Mute	 Down	 Down
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Ch. List	 Smart
 4	 4	 Exit	 Exit
 5	 5	 Vol +	 Vol +
 6	 6	 Vol -	 Vol -
 7	 7	 Sound	 Shift + Dual
 8	 8	 Ch +	 Ch +
 9	 9	 Ch -	 Ch -
 0	 0	 PIC	 Shift + Format
 Audio	 Dual	 Text	 Text
 Recall	 Back	 Aspect	 Format
 TV Menu	 Menu	 Freeze	 Pause
 Source	 AV	 EPG	 Guide
 Up	 Up	 Sleep	 Sleep





Original		Replacement		Original	Replacement
	TV / RADIO		TV/R		
	Info		Info		
	FAV		Pre Ch		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	Reveal		Media		
	Hold		Stop		
	List		List		
	Subpage		<<		
	Size		Eject		
	Mix		>>		
	Subtitle		Subt		
	Index		Play		

