






Original	Replacement
 Power	 Power
 Sleep	 Sleep
 Exit	 Exit
 I-II	 Dual
 I.S.	 Smart
 [i+]	 Info
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Smart Audio	 Shift + Dual

Original	Replacement
 Smart Picture	 Format
 Menu	 Menu
 Text / OK	 Ok
 Text / OK	 Text
 Up	 Up
 Left	 Left
 Right	 Right
 Down	 Down
 Vol +	 Vol +
 Vol -	 Vol -
 Mute	 Mute
 P +	 Ch +
 P -	 Ch -
 Red / Rec	 Red
 Red / Rec	 Rec
 Green / <<	 Green
 Green / <<	 <<





Original	Replacement	Original	Replacement
 Yellow / Stop	 Yellow		
 Yellow / Stop	 Stop		
 Blue / Play	 Blue		
 Blue / Play	 Play		
 [X]	 SHIFT +  CLEAR EXIT Shift + Exit		
 [♦] / ⊕	 ECO 3D 3D		
 [□] / >>	 SHIFT +  Shift + Stop		
 [□] / >>	 >> >>		
 [/≡]	 SHIFT +  REPEAT TEXT Shift + Text		
 [?]	 SEARCH TV/R TV/R		
 [≡i]	 GUIDE Guide		

