































































Original	Replacement
	
Power	Power
	
Stop	Stop
	
Pause	Pause
	
Rec	Rec
	
<<	<<
	
Play	Play
	
>>	>>
	
*	Menu
	
Search	TV/R
	
Bluetooth	Pre Ch
	
TV Guide	Guide
	
List	List
	
Sources	AV
	
Smart Tv	Smart
	
Home	Shift + Smart
	
Exit/TV	Exit
	
Red	Red

Original	Replacement
	
Green	Green
	
Yellow	Yellow
	
Blue	Blue
	
Info	Info
	
Options	Options
	
←/Back	Back
	
[<>]/Format	Format
	
Up	Up
	
Down	Down
	
Right	Right
	
Left	Left
	
OK	Ok
	
Vol+	Vol +
	
Vol-	Vol -
	
Mute	Mute
	
Netflix	Media
	
CH+	Ch +





Original		Replacement		Original		Replacement	
	CH-		Ch -				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Subtitle		Subt				
	Text		Text				

