



Original	Replacement
Power	Power
CD	Up
Bluetooth /	Left
FM	Down
USB /Audio In	Right
I<<	I<<
Play	Play
Pause	Pause
>>I	>>I
Stop	Stop
Mode	Smart
Dim	Media
Album / Preset Up	Ch +
Album / Preset	Ch -
Sound	Dual
Vol +	Vol +
Vol -	Vol -

Original	Replacement
Mute	Mute
Info	Info
Prog / Scan	Options
Sleep / Timer	Sleep
Clock	AV

