







































































Original		Replacement		Original		Replacement	
	Power		Power		Mute		Mute
	3D		3D		i		Info
	Source		AV		P+		Ch +
	1		1		P-		Ch -
	2		2		Menu		Menu
	3		3		Q.Menu		D. Menu
	4		4		Back		Back
	5		5		Exit		Exit
	6		6		Up		Up
	7		7		Down		Down
	8		8		Right		Right
	9		9		Left		Left
	0		0		OK		Ok
	TV		TV/R		Internet		Smart
	Recall		Pre Ch		Music/Photo/Video		Options
	Vol+		Vol +		Guide		Guide
	Vol-		Vol -		*1/O		Format





Original		Replacement		Original		Replacement	
	*2/Q		Eject				
	[≡]		Text				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Lang		Dual				
	[≡]...		Subt				
	[-o-]		List				
	<<		<<				
	Pause		Pause				
	>>		>>				
	Rec		Rec				
	Play		Play				
	Stop		Stop				

