







































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TV Portal		Smart
	Menu		Menu
	Play		Play
	Pause		Pause
	Stop		Stop
	Rec		Rec
	<<		<<
	>>		>>
	<< / ⌂		<<
	>> / ⌂		>>
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Media		Media
	Guide		Guide
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Exit		Exit





Original	Replacement
Back	Back
Vol +	Vol +
Vol -	Vol -
List	List
i	Info
P+ / Page +	Ch +
P- / Page -	Ch -
OPT+	Options
Sound	Dual
SUB	Subt
TV / Radio	TV/R
Text	Text
+ Book	Shift + Pre Ch
Book	Pre Ch
I>	Shift + Right
Source	AV
Sleep	Sleep

Original	Replacement
V-Format	Format
Wide	3D

