

















































| Original  |          | Replacement   |       | Original  |          | Replacement   |        |
|---|----------|---|-------|---|----------|---|--------|
|    | Standby  |    | Power |    | Tv/Radio |    | TV/R   |
|    | Mute     |    | Mute  |    | Menu     |    | Menu   |
|    | 1        |    | 1     |    | Exit     |    | Exit   |
|    | 2        |    | 2     |    | Up       |    | Up     |
|    | 3        |    | 3     |    | Down     |    | Down   |
|    | 4        |    | 4     |    | Right    |    | Right  |
|    | 5        |    | 5     |    | Left     |    | Left   |
|    | 6        |    | 6     |    | OK       |    | Ok     |
|    | 7        |    | 7     |    | Vol+     |    | Vol +  |
|    | 8        |    | 8     |    | Vol-     |    | Vol -  |
|   | 9        |   | 9     |   | CH+      |   | Ch +   |
|  | 0        |  | 0     |  | CH-      |  | Ch -   |
|  | Info     |  | Info  |  | TTX      |  | Text   |
|  | Recall   |  | Back  |  | FAV      |  | Pre Ch |
|  | EPG      |  | Guide |  | Media    |  | Media  |
|  | Audio    |  | Dual  |  | USB      |  | Smart  |
|  | Subtitle |  | Subt  |  | Record   |  | Rec    |



