

































































































Original		Replacement		Original		Replacement	
	Power		Power		Prog+		Ch +
	1		1		Prog-		Ch -
	2		2		Menu		Menu
	3		3		List		List
	4		4		Back		Back
	5		5		Exit		Exit
	6		6		Up		Up
	7		7		Left		Left
	8		8		OK		Ok
	9		9		Right		Right
	0		0		Down		Down
	EPG		Guide		Red / Timer		Red
	Info		Info		Red / Timer		AV
	Vol+		Vol +		Green / FAV		Green
	Vol-		Vol -		Green / FAV		Pre Ch
	Mute		Mute		Yellow / Repeat		Yellow
	TV / Radio		TV/R		Blue / Goto		Blue





Original	Replacement	Original	Replacement
 Audio	 Dual		
 SUB	 Subt		
 Yellow / Repeat	 Shift + Text		
 Text	 Text		
 File	 Media		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		
 Rec	 Rec		
 I<< PREV	 I<<		
 >>I NEXT	 >>I		
 << REW	 <<		
 >> FWD	 >>		

