








Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 EPG	 Guide
 Info	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 Smart	 Smart
 Mute	 Mute

Original	Replacement
 Prog+	 Ch +
 Prog-	 Ch -
 Menu	 Menu
 List	 List
 Back	 Back
 Exit	 Exit
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Audio	 Dual
 Sub	 Subt





Original	Replacement
Text	Text
2View	TV/R
APP	Media
Play / Pause	Play
Play / Pause	Pause
Stop	Stop
Rec	Rec
I<< PREV	I<<
>>I NEXT	>>I
<< REW	<<
>> FWD	>>

Original	Replacement

