





















































Original	Replacement	Original	Replacement
 Power	 Power	 -/--	 Shift + Guide
 Mute	 Mute	 TV Menu	 Menu
 Source	 AV	 DVB Menu	 D. Menu
 PMode	 Format	 D.Exit	 Exit
 SMode	 Shift + Dual	 QV	 Pre Ch
 I/II	 Dual	 Call	 Back
 Sleep	 Sleep	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 V-	 Vol -
 6	 6	 V+	 Vol +
 7	 7	 P-	 Ch -
 8	 8	 P+	 Ch +
 9	 9	 Red	 Red
 0	 0	 Green	 Green





Original	Replacement	Original	Replacement
 Yellow	 Yellow		
 Blue	 Blue		
 Subtitle	 Subt		
 Size	 3D		
 Hold	 Stop		
 Reveal	 Smart		
 TV / Text	 Text		
 Index	 Shift + Info		
 Cancel	 Shift + Back		
 Mix	 Shift + Text		
 Subpage	 Shift + Subt		
 FAV	 Shift + Pre Ch		
 Info	 Info		
 Language	 Options		
 TV / Radio	 TV/R		
 EPG	 Guide		

Original	Replacement

