


































































	Original	Replacement		Original	Replacement
	Power		Power		Angle/TTX
	Goto		Back		Audio
	Mute		Mute		PBC/Scan
	Source		AV		Title
	1		1		Stop
	2		2		Play
	3		3		Pause
	4		4		Mode
	5		5		Setup
	6		6		Up
	7		7		Down
	8		8		Right
	9		9		Left
	0		0		Enter
	10+		Pre Ch		Yellow/Zoom
	Step		Smart		Red/Menu
	Subtitle		Subt		Green
					Text
					Dual
					Media
					3D
					Play
					Format
					Options
					Up
					Down
					Right
					Left
					Ok
					Yellow
					Red
					Green





	Original	Replacement		
	Blue		Blue	
	l<<		l<<	
	>>l		>>l	
	TV/Radio		TV/R	
	Repeat/Del	+	Shift + Text	
	Pro/EPG		Guide	
	Display		Info	
	<</FAV		<<	
	>>/Prot		>>	

	Original	Replacement

