



Original		Replacement		Original		Replacement	
	Power		Power		FAV		Pre Ch
	Mute		Mute		Page+		Ch +
	1		1		Page-		Ch -
	2		2		Up/CH+		Up
	3		3		Down/CH-		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		OK		Ok
	7		7		Vol+		Vol +
	8		8		Vol-		Vol -
	9		9		Red		Red
	0		0		Green		Green
	Info		Info		Yellow		Yellow
	Recall		Back		Blue		Blue
	Menu		Menu		Audio		Dual
	EPG		Guide		Pause		Pause
	Exit		Exit		TTX		Text





	Original	Replacement	Original	Replacement
	Subtitle	 Subt		
	Tv/Radio	 TV/R		

