



































































































Original	Replacement	Original	Replacement
 Power	 Power	 Yellow	 Yellow
 Mute	 Mute	 Blue	 Blue
 1	 1	 i	 Info
 2	 2	 Text	 Text
 3	 3	 Up / P+	 Up
 4	 4	 Up / P+	 Ch +
 5	 5	 Down / P-	 Down
 6	 6	 Down / P-	 Ch -
 7	 7	 Right / Vol+	 Vol +
 8	 8	 Right / Vol+	 Right
 9	 9	 Left / Vol-	 Vol -
 0 / AV	 0	 Left / Vol-	 Left
 0 / AV	 AV	 Menu / OK	 Menu
 Red / Zoom	 Red	 Menu / OK	 Ok
 Red / Zoom	 Eject	 Stop	 Stop
 Green / Audio	 Green	 F.T/L	 Smart
 Green / Audio	 Dual	 [?]	 Media





















	Original	Replacement	Original	Replacement
	Power			
	Menu			
	OK			
	Up			
	Down			
	Right			
	Left			
	<<			
	Play			
	>>			
	Stop			
	Rec			
	↑			
	↓			





Original	Replacement	Original	Replacement
 Power	 Power		
 <<	 <<		
 Play	 Play		
 >>	 >>		
 Rec	 Rec		
 Stop	 Stop		
 Up	 Up		
 Down	 Down		

