



Original	Replacement	Original	Replacement
 Power	 Power	 Up	 Up
 Source	 AV	 Left	 Left
 Rec	 Rec	 OK	 Ok
 APP	 Media	 Right	 Right
 <<	 <<	 Down	 Down
 Play / Pause	 Play	 EPG	 Guide
 Play / Pause	 Pause	 Back	 Back
 >>	 >>	 Vol+	 Vol +
 I<<	 I<<	 Vol-	 Vol -
 Stop	 Stop	 Info	 Info
 >>I	 >>I	 Mute	 Mute
 Red	 Red	 Prog+	 Ch +
 Green	 Green	 Prog-	 Ch -
 Yellow	 Yellow	 1	 1
 Blue	 Blue	 2	 2
 Menu	 Menu	 3	 3
 Exit	 Exit	 4	 4



















































Original		Replacement		Original		Replacement	
5 jkl	5	5	5				
6 mno	6	6	6				
7 pqrs	7	7	7				
8 tuv	8	8	8				
9 wxyz	9	9	9				
0 _	0	0	0				
AUDIO	Audio	SOUND DUAL	Dual				
SUB	Sub	AD SUBT	Subt				
LIST	List	DISC NAV LIST	List				
TEXT	Text	REPEAT TEXT	Text				
REC LIST	Rec List	HOME SMART	Smart				





Original		Replacement		Original		Replacement	
	Power		Power		6		6
	APP		Media		7		7
	Menu		Menu		8		8
	Exit		Exit		9		9
	OK		Ok		0		0
	Back		Back		Text		Text
	Vol+		Vol +				
	Vol-		Vol -				
	Info		Info				
	Mute		Mute				
	Prog+		Ch +				
	Prog-		Ch -				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				

