















































































































Original	Replacement	Original	Replacement
	Power		Power
	TV/AV		AV / Input / RDS
	TV/TXT		Text / Goto
	Cancel		Shift + Exit / Cancel / Clear
	Reveal		Shift + Smart / List
	DTV		Setup / OPT /
	Hold		Stop / Hold
	Size		Zoom / Size
	Subpage		Shift + Display / Media
	Index		Display / Media
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	CH+		CH+ / Page+
	Menu		Menu / Home
	Vol+		Vol+
	CH-		CH- / Page-
	Exit		Exit / Cancel / Clear
	Vol-		Vol-
	Channel List		Smart / List
	Mute		Mute / Dimmer
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	EPG		Guide / EPG / -/--
	Down		Down
	Info		Info / Angle
	1		1
	2		2
	3		3
	4		4
	5		5





	Original	Replacement		Original	Replacement
	6	 6		>>	 >>  / Preset+
	7	 7		Play	 Play / Slow
	8	 8		Pause	 Pause / Step / Freeze
	9	 9			
	FAV	 Fav / Marker / PC			
	0	 0			
	Recall	 Back / Return			
	Picture	 Picture / Format			
	Sound	 Sound / Title			
	Nicam/A2	 Audio / Lang I/II			
	Sleep	 Sleep / Timer			
	Subtitle	 Subtitle / EQ			
	Tv/Radio	 TV/Radio /			
	<<	 << / Tune-			
	>>	 >> / Tune+			
	Repeat	 Shift + Green / APP /			
	I<<	 I<< / Preset-			

