














































Original	Replacement	Original	Replacement
	Power		Power
	TV/VTR		TV/Radio /
	Eject		Eject / Surround
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide / EPG / -/--
	Prog+		CH+ / Page+
	Prog-		CH- / Page-
	Vol+		Vol+
	Vol-		Vol-
	Play		Play / Slow
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Search >>		>> / Tune+
	Index Search >>		>> / Preset+
	I<< Index Search		I<< / Preset-
	X2		Smart / List
	<< Search		<< / Tune-
	Skip		Exit / Cancel / Clear
	Wheel >/Frame		Shift + >> / Preset+
	Up		Up
	< Wheel/<		Shift + I<< / Preset-
	Down		Down
	Right		Right
	Left		Left
	Menu		Menu / Home





Original	Replacement
Power	Power
Display	Display / Media
TV/VTR	TV/Radio /
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/--	Guide / EPG / -/--
Vol+	Vol+
Vol-	Vol-
Prog+	CH+ / Page+

Original	Replacement
Prog-	CH- / Page-
Audio Monitor	Audio / Lang I/II
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
[≡]	Text / Goto
[]	Smart / List

