


































































Original		Replacement		Original		Replacement	
	Standby		Power		Canc		Exit / Cancel / Clear
	Equalizzatore		Shift + Sound / Title		0/10		0
	Surround		Shift + Eject / Surround		10+		Guide / EPG / -/-
	Eject		Eject / Surround		Titolo		Sound / Title
	Audio		Audio / Lang I/II		Up		Up
	1		1		Menu		Menu / Home
	2		2		Left		Left
	3		3		OK		OK
	Angle		Info / Angle		Right		Right
	4		4		Programm		TV/Radio /
	5		5		Down		Down
	6		6		Display		Display / Media
	Sottotitoli		Subtitle / EQ		PAL/NTSC		D.Menu / Top
	7		7		Setup		Setup / OPT /
	8		8		Digest		Shift + D.Menu / Top Menu
	9		9		Vol+		Vol+
	Ricerca		Red / Netflix / Search		Mute		Mute / Dimmer





	Original	Replacement	Original	Replacement
	 Mark	 Fav / Marker / PC		
	 Zoom	 Zoom / Size		
	 Vol-	 Vol-		
	 A-B	 Yellow / YouTube / Repeat		
	 Ripeti	 Back / Return		
	 Slow	 Shift + Play /		
	 <</F.RWD	 << / Tune-		
	 F.FWD/>>	 >> / Tune+		
	 I<< / Skip-	 I<< / Preset-		
	 >>I / Skip+	 >>I / Preset+		
	 Stop	 Stop / Hold		
	 Pause/Step	 Pause / Step / Freeze		
	 Play	 Play / Slow		

