





































| Original | Replacement |
|---|---|
|  A.Space/A.Cue |  Smart |
|  Music Scan |  Media |
|  Play Mode |  Dual |
|  Play Mode Shuffle |  Subt |
|  Play Mode |  Options |
|  Clear |  Exit |
|  Fader |  Mute |
|  Repeat |  Text |
|  Time |  AV |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |

| Original | Replacement |
|---|---|
|  9 |  9 |
|  10 |  0 |
|  >10 |  Guide |
|  Line Out Level+ |  Vol + |
|  Line Out Level- |  Vol - |
|  Play |  Play |
|  Pause |  Pause |
|  Stop |  Stop |
|  >> |  >> |
|  << |  << |
|  >> |  >> |
|  << |  << |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

