










































































Original		Replacement		Original		Replacement	
	Power		Power		Green		Green
	Input TV		TV/R		Yellow		Yellow
	Input AV		AV		Blue		Blue
	Aspect		Format		Text		Text
	Viera Link		Media		[≡♦]/Sttl		Subt
	Option		Options		[≡i]/Index		List
	SD Card		3D		[≡+]/Hold		D. Menu
	Guide		Guide		1		1
	Exit		Exit		2		2
	Up		Up		3		3
	Left		Left		4		4
	OK		Ok		5		5
	Right		Right		6		6
	Down		Down		7		7
	Menu		Menu		8		8
	Return		Back		9		9
	Red		Red		0		0





Original	Replacement
 i	 INFO Info
 Mute	 MUTE Mute
 CH+	 + CH Ch +
 CH-	 - CH Ch -
 Vol+	 + VOL Vol +
 Vol-	 - VOL Vol -
 Programme	 SHIFT + - CH Shift + Ch -
 Programme Up	 SHIFT + + CH Shift + Ch +
 <</ <<	 << <<
 >>/>>	 >> >>
 Stop	 Stop
 Pause/Step	 Pause
 Play	 PLAY MODE Play
Power Down	 SHIFT +  Shift + Power
Rec	 REC MODE Rec
N	 FAV PRE-CH Pre Ch
Direct Tv Rec	 SHIFT +  REC MODE Shift + Rec

Original	Replacement
Viera Tools	 HOME SMART Smart
OIO	 ZOOM Eject

