

































































































Original		Replacement		Original		Replacement	
	Power		Power		Source		AV
	Mute		Mute		Subtitle		Subt
	TV / Radio		TV/R		Return		Back
	P-Mode		Format		Fav		Pre Ch
	S-Mode		Dual		Smart Hub		Smart
	1		1		Up		Up
	2		2		Left		Left
	3		3		OK		Ok
	4		4		Right		Right
	5		5		Down		Down
	6		6		Exit		Exit
	7		7		EPG		Guide
	8		8		Vol+		Vol +
	9		9		Vol-		Vol -
	0		0		Info		Info
	Menu		Menu		CH. List		3D
	Index		Media		CH+		Ch +





Original	Replacement	Original	Replacement
 CH-	 Ch -		
 Play / Pause	 Play		
 Play / Pause	 Pause		
 <<<	 <<<		
 >>>	 >>>		
 Rec	 Rec		
 Stop	 Stop		
 I<<<	 I<<<		
 >>>I	 >>>I		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

