















































































Original	Replacement	Original	Replacement
	Power		Power
	Input		AV
	Text		Text
	T.Opt		Options
	AD		Subt
	*		Menu
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0 / Quick Access		0
	List		List
	...		3D
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Search		Shift + TV/R
	TV		TV/R
	CH+		Ch +
	CH-		Ch -
	Home		Smart
	Netflix		Shift + Red
	Prime Video		Shift + Green
	Disney+		Shift + Blue
	Rakuten TV		Shift + Yellow
	Up		Up
	Left		Left
	OK		Ok
	Right		Right





Original	Replacement	Original	Replacement
 Down	 Down		
 Back	 Back		
 Exit	 Exit		
 Guide	 Guide		
 Rec	 Rec		
 Stop	 Format		
 <<	 <<		
 Play	 Play		
 Pause	 Pause		
 >>	 >>		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

