



Original	Replacement	Original	Replacement
 Power	 Power	 Down	 Down
 Input+	 Ch +	 Right	 Right
 Input-	 Ch -	 Left	 Left
 Clear Audio+	 Exit	 OK	 Ok
 Display	 Info	 SW Vol+	 Shift + Vol +
 Voice	 Sleep	 SW Vol-	 Shift + Vol -
 Night	 Media	 Play	 Play
 Bluetooth/Pairing	 TV/R	 <<	 <<
 Music Service	 Subt	 >>	 >>
 Dimmer	 Pre Ch	 Pause	 Pause
 Options	 Options	 I<<	 I<<
 Back	 Back	 >>I	 >>I
 Home	 Smart	 Stop	 Stop
 Mute	 Mute	 Sound Field	 3D
 Vol+	 Vol +	 Audio	 Dual
 Vol-	 Vol -	 Bluetooth RX/TX	 Text
 Up	 Up	 Red	 Red



