




















	Original	Replacement		Original	Replacement
	Phono	 1	1		
	CD	 2	2		
	Tuner	 3	3		
	Aux	 4	4		
	Tape1	 5	5		
	Tape2	 6	6		
	Vol+	 + VOL	Vol +		
	Vol-	 - VOL	Vol -		
	Mute	 MUTE	Mute		

