









































































Original	Replacement
	 Power
	 Red
	 Green
	 AV
	 Shift + Red
	 Yellow
	 Blue
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0

Original	Replacement
	 Guide
	 Exit
	 Ch +
	 Ch -
	 Vol +
	 Vol -
	 I<<
	 >>I
	 <<
	 >>
	 Stop
	 Pause
	 Play
	 Shift + Menu
	 List
	 Menu
	 Up






















Original	Replacement
	 Left
	 Ok
	 Right
	 Down
	 Smart
	 Back
	 +  Shift + Dual
	 +  Shift + Options
	 +  Shift + D. Menu
	 D. Menu
	 3D
	 Format
	 +  Shift + Format
	 Sleep
	 Info
	 Eject
	 +  Shift + >>I







Original	Replacement
	 Dual
	 Subt
	 Mute
	 Options
	 +  Shift + Info
	 TV/R
	 +  Shift + TV/R
	 Text
	 +  Shift + Play
	 +  Shift + Smart
	 Media
	 +  Shift + Pause
	 Pre Ch
	 +  Shift + Text







Original	Replacement
	 Power
	 Shift + Power
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 Guide
	 >>I
	 I<<
	 <<
	 >>

Original	Replacement
	 Pause
	 Play
	 Stop

