



































































































































| Original | | Replacement | | Original | | Replacement | |
|---|------------------|---|---------------|---|-------------|---|--------|
|  | Main Power On |  | Power |  | 4 |  | 4 |
|  | Main Power Off |  | Shift + Power |  | 5 |  | 5 |
|  | Source Power |  | AV |  | 6 |  | 6 |
|  | Mute |  | Mute |  | 7 |  | 7 |
|  | Volume+ |  | Vol + |  | 8 |  | 8 |
|  | Volume- |  | Vol - |  | 9 |  | 9 |
|  | Phono |  | Shift + 1 |  | 0 |  | 0 |
|  | CD |  | Shift + 2 |  | + |  | Pre Ch |
|  | Tuner |  | Shift + 3 |  | - |  | Guide |
|  | Recorder 1 /CD-R |  | Shift + 4 |  | A F/P |  | Smart |
|  | AUX |  | Shift + 5 |  | B -/-- |  | Media |
|  | DVD |  | Shift + 6 |  | Mode |  | Format |
|  | Recorder |  | Shift + 7 |  | Memo |  | Rec |
|  | Recorder 2/MD |  | Shift + 8 |  | SCroll |  | Info |
|  | 1 |  | 1 |  | Cancel |  | Back |
|  | 2 |  | 2 |  | Text/1 Mode |  | Text |
|  | 3 |  | 3 |  | Time/Mode 2 |  | 3D |









































































| Original | Replacement | Original | Replacement |
|--|---|--|---|
|  Main Power On |  Power |  Text/1 Mode |  Text |
|  Main Power Off |  Shift + Power |  Time/Mode 2 |  3D |
|  Source Power |  AV |  Mute |  Mute |
|  1 |  1 |  Volume+ |  Vol + |
|  2 |  2 |  Volume- |  Vol - |
|  3 |  3 |  Play |  Play |
|  4 |  4 |  >> |  >> |
|  5 |  5 |  << |  << |
|  6 |  6 |  Stop |  Stop |
|  7 |  7 |  << |  << |
|  8 |  8 |  >> |  >> |
|  9 |  9 |  Pause |  Pause |
|  0 |  0 |  Open/Close |  Eject |
|  + |  Pre Ch | | |
|  - |  Guide | | |
|  A F/P |  Smart | | |
|  B -/- |  Media | | |









































































| Original | Replacement | Original | Replacement |
|--|---|--|---|
|  Main Power On |  Power |  - |  Guide |
|  Main Power Off |  Shift + Power |  A F/P |  Smart |
|  Source Power |  AV |  B -/-- |  Media |
|  Mute |  Mute |  Mode |  Format |
|  Volume+ |  Vol + |  Memo |  Rec |
|  Volume- |  Vol - |  Scroll |  Info |
|  1 |  1 |  Cancel |  Back |
|  2 |  2 |  Text/1 Mode |  Text |
|  3 |  3 |  Time/Mode 2 |  3D |
|  4 |  4 |  Play |  Play |
|  5 |  5 |  >> |  >> |
|  6 |  6 |  << |  << |
|  7 |  7 |  Stop |  Stop |
|  8 |  8 |  >> |  >> |
|  9 |  9 |  << |  << |
|  0 |  0 |  Pause |  Pause |
|  + |  Pre Ch |  Open/Close |  Eject |





| Original | Replacement | Original | Replacement |
|--|---|--|---|
|  Main Power On |  Power |  Mode |  Format |
|  Main Power Off |  Shift + Power |  Memo |  Rec |
|  Source Power |  AV |  Cancel |  Back |
|  1 |  1 |  Text/1 Mode |  Text |
|  2 |  2 |  Time/Mode 2 |  3D |
|  3 |  3 |  Mute |  Mute |
|  4 |  4 |  Volume+ |  Vol + |
|  5 |  5 |  Volume- |  Vol - |
|  6 |  6 |  Play |  Play |
|  7 |  7 |  >> |  >> |
|  8 |  8 |  << |  << |
|  9 |  9 |  Stop |  Stop |
|  0 |  0 |  >> |  >> |
|  + |  Pre Ch |  << |  << |
|  - |  Guide |  Pause |  Pause |
|  A F/P |  Smart |  <> |  Blue |
|  B -/- |  Media |  Open/Close |  Eject |

