







































































Original	Replacement	Original	Replacement
 POWER	 Power	 ARC	 Smart
 CH+	 Ch +	 APC	 Media
 CH-	 Ch -	 UP	 Up
 VOL+	 Vol +	 LEFT	 Left
 VOL-	 Vol -	 OK	 Ok
 1	 1	 RIGHT	 Right
 2	 2	 DOWN	 Down
 3	 3	 MENU	 Menu
 4	 4	 EXIT	 Exit
 5	 5	 TELETEXT	 Text
 6	 6	 Index	 Play
 7	 7	 Clock / Subpage	 Pause
 8	 8	 Hold	 Stop
 9	 9	 Reveal	 Rec
 0	 0	 Cancel	 <<
 MUTE	 Mute	 Size	 >>
 RTN.	 Back	 RED	 Red



