







































































Original	Replacement	Original	Replacement
 Power	 Power	 Yellow	 Yellow
 Input	 AV	 Blue	 Blue
 1	 1	 [=]	 Menu
 2	 2	 Pause	 Pause
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 OK	 Ok
 8	 8	 Back	 Back
 9	 9	 Exit	 Exit
 0	 0	 Vol+	 Vol +
 Guide	 Guide	 Vol-	 Vol -
 CH.List	 List	 Home	 Smart
 Play	 Play	 Micro	 Media
 Red	 Red	 CH+	 Ch +
 Green	 Green	 CH-	 Ch -





Original	Replacement	Original	Replacement
Subtitle	Subt		
Mute	Mute		
Text	Text		
Free	Options		
Sports	TV/R		
Chili	Dual		
Netflix	Shift + Media		
prime video	3D		
YouTube	Pre Ch		
TV Timvision	Shift + TV/R		
Rakuten Tv	D. Menu		
Rai Play	Shift + Smart		

Original	Replacement

