




























































































Original	Replacement	Original	Replacement
	 Zoom / Size		 0
	 Power		 Display / Media
	 TV/Radio /		 Setup / OPT /
	 Guide / EPG / -/--		 Up
	 Info / Angle		 Menu / Home
	 Picture / Format		 Left
	 AV / Input / RDS		 OK
	 1		 Right
	 2		 Back / Return
	 3		 Down
	 4		 Exit / Cancel / Clear
	 5		 Vol+
	 6		 Fav / Marker / PC
	 7		 CH+ / Page+
	 8		 Vol-
	 9		 Audio / Lang I/II
	 Smart / List		 CH- / Page-





Original	Replacement	Original	Replacement
 Mute	 Mute / Dimmer		
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow / Brightness-	 Yellow / YouTube / Repeat		
 Blue /	 Blue / Prime Video / Random		
 Stop	 Stop / Hold		
 Play	 Play / Slow		
 Pause	 Pause / Step / Freeze		
 Subtitle	 Subtitle / EQ		
 <<	 << / Tune-		
 <<	  << / Preset-		
 >>	 >> / Tune+		
 >>	 >>  / Preset+		
 Text	 Text / Goto		
 T.Opt	 D.Menu / Top		

Original	Replacement	Original	Replacement

