












































| Original | Replacement |
|--|--|
|  TV / Input |  AV / Input / RDS |
|  Wide |  Picture / Format |
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  []Y]Reveal |  Smart / List |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  →← |  Display / Media |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  Mute |  Mute / Dimmer |
|  -/-- / Subcode |  Guide / EPG / -/-- |
|  0 |  0 |

| Original | Replacement |
|---|---|
|  CS |  Fav / Marker / PC |
|  P↔P |  Back / Return |
|  F Subtitle / OK |  Subtitle / EQ |
|  F Subtitle / OK |  OK |
|  Up / P+ |  Up |
|  Up / P+ |  CH+ / Page+ |
|  Menu / Index |  Menu / Home |
|  Left / Vol- |  Left |
|  Left / Vol- |  Vol- |
|  Right / Vol+ |  Right |
|  Right / Vol+ |  Vol+ |
|  Down / P- |  Down |
|  Down / P- |  CH- / Page- |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow / Bass |  Yellow / YouTube / Repeat |
|  Blue / Timer |  Blue / Prime Video / Random |



