







































































Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 Epg / Setup	 Picture / Format
 Dvd / Av / Dtv	 AV / Input / RDS
 Dvd/usb/Card	 Shift + 2
 Info / Osd	 Info / Angle
 →←Search	 Zoom / Size
 Audio	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 Menu	 Menu / Home
 Exit/Title	 Exit / Cancel / Clear
 Fav / Zoom	 Fav / Marker / PC
 Up	 Up
 Ch+	 CH+ / Page+
 Down	 Down
 Ch-	 CH- / Page-
 Left	 Left

Original	Replacement
 Vol-	 Vol-
 Right	 Right
 Vol+	 Vol+
 Ok	 OK
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/10	 0
 10+	 Guide / EPG / -/-
 Dvd Vol+	 Shift + Vol+
 Dvd Vol-	 Shift + Vol-





Original		Replacement		Original		Replacement	
	Tv-R / Repeat		TV/Radio /				
	Text / Program		Text / Goto				
	Stop		Stop / Hold				
	Pause		Pause / Step / Freeze				
	Play		Play / Slow				
	I<< / Prev		I<< / Preset-				
	>>I / Next		>>I / Preset+				
	<< / Rev		<< / Tune-				
	>> / Fwd		>> / Tune+				

