








































































Original	Replacement	Original	Replacement
 Power	 Power	 FAV/Mark	 Fav / Marker / PC
 e/Energy Saving	 Shift + OK	 Ratio	 Picture / Format
 AV Mode	 Text / Goto	 Mute/Delete	 Mute / Dimmer
 Input	 AV / Input / RDS	 Vol+	 Vol+
 TV	 TV/Radio /	 Vol-	 Vol-
 1	 1	 CH+	 CH+ / Page+
 2	 2	 CH-	 CH- / Page-
 3	 3	 Menu	 Menu / Home
 4	 4	 Netcast	 Display / Media
 5	 5	 Q.Menu	 D.Menu / Top
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Left	 Left
 9	 9	 Right	 Right
 0	 0	 Enter	 OK
 List	 Smart / List	 Back	 Back / Return
 Q.View	 Setup / OPT /	 Simplink	 Zoom / Size





Original		Replacement		Original		Replacement	
	Exit		Exit / Cancel / Clear				
	Red		Red / Netflix / Search				
	Green		Green / APP / Repeat				
	Yellow		Yellow / YouTube / Repeat				
	Blue		Blue / Prime Video / Random				
	Stop		Stop / Hold				
	Play		Play / Slow				
	Pause		Pause / Step / Freeze				
	<<		<< / Tune-				
	>>		>> / Tune+				

