



Original	Replacement
	 Power
	 ambilight
	 Menu / Home
	 Sound / Title
	 AV / Input / RDS
	 Up
	 Down
	 Right
	 Left
	 OK
	 Back / Return
	 Shift + Menu /
	 Display / Media
	 << / Tune-
	 Play / Slow
	 >> / Tune+
	 Stop / Hold

Original	Replacement
	 Pause / Step / Freeze
	 Rec / Rec Mode
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Vol+
	 Vol-
	 Mute / Dimmer
	 CH+ / Page+
	 CH- / Page-
	 Exit / Cancel / Clear
	 Shift + Red / Netflix /
	 Smart / List
	 Shift + Yellow / YouTube /
	 1
	 2





Original	Replacement
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 Text / Goto
	 Tv Guide/List Guide / EPG / -/--

Original	Replacement

