Original		Replacement	
Power		Power	
Mute		Mute / Dimmer	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
Audio		Audio / Lang I/II	
0		0	
Recall		Back / Return	
Aspect		+	Shift + Picture / Format
Sound		Sound / Title	
APP		Display / Media	

Original		Replacement	
Vol+		Vol+	
Home		+	Shift + Menu /
Home		D.Menu / Top	
CH+		CH+ / Page+	
Vol-		Vol-	
EPG		Guide / EPG / -/--	
CH-		CH- / Page-	
Picture		Picture / Format	
TV		+	Shift + 1
TV		TV/Radio /	
USB		+	Shift + 8
Menu		Menu / Home	
Up		Up	
Source		AV / Input / RDS	
Left		Left	
OK		OK	
Right		Right	

Original		Replacement	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▼	Down	▼	Down
INFO	Info / Text Index	ANGLE INFO	Info / Angle
◀◀	Red / <<	TUNE- ◀◀	<< / Tune-
◀◀	Red / <<	NETFLIX SEARCH	Red / Netflix / Search
▶▶	Green / >>	TUNE+ ▶▶	>> / Tune+
▶▶	Green / >>	APP REPEAT	Green / APP / Repeat
⏮	Yellow / I<<	PRESET- ⏮	I<< / Preset-
⏮	Yellow / I<<	YouTube REPEAT A-B	Yellow / YouTube / Repeat
⏭	Blue / >>I	PRESET+ ⏭	>>I / Preset+
⏭	Blue / >>I	Prime Video RANDOM	Blue / Prime Video / Random
⏯	Play / Pause	SLOW ▶	Play / Slow
■	Stop	HOLD ■	Stop / Hold
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
≡	Text	GOTO TEXT	Text / Goto
≡	Text Hold	SHIFT + HOLD ■	Shift + Stop /
≡	Text Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear

Original		Replacement	
≡	Text Subpage	SURROUND ⏏	Eject / Surround
≡	Text Reveal	SHIFT + SLOW ▶	Shift + Play /
≡	Text Size	SIZE ZOOM	Zoom / Size
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
SUB	SUB	EQ SUBTITLE	Subtitle / EQ
LIST	List	LIST SMART	Smart / List

Original		Replacement	
Power		Power	
Mute		Mute / Dimmer	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
Audio		Audio / Lang I/II	
0		0	
Recall		Back / Return	
Aspect		Setup / OPT /	
Aspect		Shift +	Picture / Format
Sound		Sound / Title	

Original		Replacement		
APP		Display / Media		
Vol+		Vol+		
Home		Shift +	Menu /	
Home		D.Menu / Top		
CH+		CH+ / Page+		
Vol-		Vol-		
EPG		Guide / EPG / -/--		
CH-		CH- / Page-		
Picture		Picture / Format		
TV		TV/Radio /		
TV		Shift +	1	
USB		Shift +	8	
Menu		Menu / Home		
Up		Up		
Source		AV / Input / RDS		
Left		Left		
OK		OK		

Original		Replacement	
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
INFO	Info / Text Index	ANGLE INFO	Info / Angle
	Red / <<	TUNE-	<< / Tune-
	Red / <<	NETFLIX SEARCH	Red / Netflix / Search
	Green / >>	TUNE+	>> / Tune+
	Green / >>	APP REPEAT	Green / APP / Repeat
	Yellow / I<<	PRESET-	I<< / Preset-
	Yellow / I<<	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue / >>I	PRESET+	>>I / Preset+
	Blue / >>I	Prime Video RANDOM	Blue / Prime Video / Random
	Play/Pause	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
	Text	GOTO TEXT	Text / Goto
	Text Hold	SHIFT + HOLD	Shift + Stop / Hold

Original		Replacement	
	Text Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
	Text Subpage	SURROUND	Eject / Surround
	Text Reveal	SHIFT + SLOW	Shift + Play /
	Text Size	SIZE ZOOM	Zoom / Size
FAV	Fav	PC FAV MARKER	Fav / Marker / PC
SUB	SUB	EQ SUBTITLE	Subtitle / EQ
LIST	List	LIST SMART	Smart / List

Original	Replacement	Original	Replacement
Power	Power	Vol +	Vol+
Mute	Mute / Dimmer	Audio	Audio / Lang I/II
1	1	CH +	CH+ / Page+
2	2	Vol -	Vol-
3	3	Aspect	Shift + Picture / Format
4	4	CH -	CH- / Page-
5	5	EPG / Set	Guide / EPG / -/--
6	6	Home	Shift + Menu /
7	7	APP	Shift + Green / APP /
8	8	Menu	Menu / Home
9	9	Up	Up
List	Smart / List	Source	AV / Input / RDS
0	0	Left	Left
Recall	Back / Return	Enter	OK
Picture	Picture / Format	Right	Right
Sound	Sound / Title	Exit	Exit / Cancel / Clear
Sleep	Sleep / Timer	Down	Down

Original	Replacement	Original	Replacement
Info	Info / Angle	Hold / Refresh	Shift + Stop /
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
<< / Index	<< / Tune-		
Play/Pause /	Play / Slow		
>> / TTX	Text / Goto		
>> / TTX	>> / Tune+		
I<< / Sub.Pg	I<< / Preset-		
>>I / Reveal	>>I / Preset+		
Stop / Mix	Stop / Hold		
Capture	Display / Media		
Subtitle	Subtitle / EQ		
Freeze	Pause / Step / Freeze		
FAV	Fav / Marker / PC		
Size / Mouse	Zoom / Size		