







































































| Original | Replacement | Original | Replacement |
|---|-------------|---|-----------------------|
|  | Power |  | Power |
|  | Sub-T |  | Subtitle / EQ |
|  | Lang |  | Audio / Lang I/II |
|  | Mute |  | Mute / Dimmer |
|  | EPG |  | Guide / EPG / -/-- |
|  | Goto |  | Shift + Text / |
|  | Page+ |  | CH+ / Page+ |
|  | TTX |  | Text / Goto |
|  | Repeat |  | Shift + Green / APP / |
|  | Page- |  | CH- / Page- |
|  | Menu |  | Menu / Home |
|  | Up/CH+ |  | Up |
|  | Exit |  | Exit / Cancel / Clear |
|  | Left |  | Left |
|  | Vol- |  | Vol- |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Vol+ |  | Vol+ |
|  | FAV |  | Fav / Marker / PC |
|  | Down |  | Down |
|  | Tv/Radio |  | TV/Radio / |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | Recall |  | Back / Return |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | Info |  | Info / Angle |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | << |  | << / Tune- |





| Original | Replacement | Original | Replacement |
|---|--|----------|-------------|
|  >> |  >> / Tune+ | | |
|  << |  << / Preset- | | |
|  >> |  >> / Preset+ | | |
|  Play |  Play / Slow | | |
|  Pause/Timeshift |  Pause / Step / Freeze | | |
|  Stop |  Stop / Hold | | |
|  Rec |  Rec / Rec Mode | | |
|  Red/PVR |  Red / Netflix / Search | | |
|  Green/V-Format |  Green / APP / Repeat | | |
|  Yellow/Aspect |  Yellow / YouTube / Repeat | | |
|  Blue/Timer |  Blue / Prime Video / Random | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Replacement | Original | Replacement |
|----------|-------------|----------|-------------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

