








Original	Replacement	Original	Replacement
Standby/On	Power	Enter	OK
Movie	Red / Netflix / Search	Right/A>E	Right
Music	Green / APP / Repeat	Down/-	Down
Sports	Yellow / YouTube / Repeat	Preset/Tune	D.Menu / Top
Game	Blue / Prime Video / Random	Auto/Man'L	Subtitle / EQ
Input 1	1	Memory	Rec / Rec Mode
Input 2	2	SW+	7
Input 3	3	Test	Text / Goto
Volume+	Vol+	Position	Setup / OPT /
Input 4	4	Area	TV/Radio /
FM	5	SW-	Guide / EPG / -/-
Dock	6	Stop	Stop / Hold
Volume-	Vol-	Pause	Pause / Step / Freeze
Stereo	Sound / Title	Play	Play / Slow
Up/+	Up	Center+	8
Mute	Mute / Dimmer	<<	<< / Tune-
Left/A<E	Left	>>	>> / Tune+





Original	Replacement	Original	Replacement
	Dock Mode		AV / Input / RDS
	Center-		0
	Bluetooth On		Picture / Format
	Bluetooth Off		Zoom / Size
	Audio Delay		Audio / Lang I/II
	SUR.+		9
	Enhancer		Smart / List
	Night		Sleep / Timer
	Disp.Mode		Info / Angle
	SUR.-		Fav / Marker / PC

Original	Replacement	Original	Replacement

