





















































































Original		Replacement		Original		Replacement	
	Standby		Power		Zoom/Aspect		3D
	Mute		Mute		CH+		Ch +
	1		1		CH-		Ch -
	2		2		Menu		Menu
	3		3		Exit		Exit
	4		4		Sleep		Sleep
	5		5		Source		AV
	6		6		Up		Up
	7		7		Down		Down
	8		8		Right		Right
	9		9		Left		Left
	0/10		0		OK/Enter		Ok
	Recall/Program		Back		Red		Red
	List/+10		List		Green/R.List		Green
	Vol+		Vol +		Yellow/TList/Title		Yellow
	Vol-		Vol -		Blue/D.Display		Blue
	Info/Display		Info		D.Setup		Smart





	Original	Replacement		Original	Replacement
	D.Menu		D. Menu		EPG
	TTX		Text		FAV
	Open/Close		Eject		
	A-B/Index		Options		
	Goto/Hold		Media		
	I/II/Audio		Dual		
	Rec/Repeat		Rec		
	Stop/Reveal		Stop		
	Play		Play		
	Pause		Pause		
	Size		Format		
	Subtitle		Subt		
	<</Subpage		<<		
	>>		>>		
	Tv/Radio		TV/R		
	I<<		I<<		
	>>I		>>I		

	Original	Replacement
	Guide	
	Pre Ch	

